



FIXING INSTRUCTIONS **For all Bolt Down Anchors**

- 1. Select a suitable location on a solid, flat concrete surface.**
- 2. Mark the hole positions on the concrete.**
- 3. Drill at each position \varnothing 16mm by a minimum of 60mm deep.**
- 4. Gently push the outer fixing part, 'the shell' into the hole until it is flush with the surface.**
- 5. Position the ground-anchor over the fixing holes.**
- 6. Locate the M10 screw through the anchor and into the 'shell' and tighten up with a 6mm Allen key.**
- 7. When all the fixings are tight, position a ball bearing into the hexagon hole in the bolt head, and hammer the ball into the head of the bolt until flush.**
- 8. Finally, place a stainless steel cover over the head of each bolt and hammer into the hole in the anchor.**

Installation is complete.